

Assembly Instructions



wedi Fundo | Niche

Includes: 1 Pc. Fundo Niche 16" x 16" or 16" x 22"

Installation:

1. wedi® Niches are installed in a cut out of the wall.
2. Insert the unit into the center of 16 o.c. studs.
3. If waterproofing, use wedi® joint sealant along the connection where the wall meets the Niche.
4. Use two to three fasteners on each side of the niche, and create a flush transition to the wall.
5. If waterproofing, apply another ½" bead of wedi® joint sealant over the seam; use a putty knife to spread.

