



Installation Instructions For wedi Sanbath Tub Units

- Mark the wedi drain before making a clean, square cut.
- Cut away the female pipe connector piece.
- Connect an adapter (wedi 50 mm pipe to a 2" pipe in the subfloor) with the wedi drain. This can also be a flexible rubber pipe connector.
- Install the tub base system in a permanent position. Use wedi Joint Sealant to glue the base frame to the floor.

- Cut out an access to the drain connection and then reinsert the cut out piece with a bead of wedi Joint Sealant.
- Apply wedi Joint Sealant to the blue foam contact surfaces on the base frame.
- Connect the wedi tub drain assembly to a 2” pipe in the subfloor.
- Place the tub unit on the base frame.
- Insert the drain cover frame into the drain opening. Fasten with the attached screws and raise the drain cover frame to the height of the tile.
- Insert the rubber o-ring and the drain lift and sink plug.
- Insert the stainless steel drain cover.
- Mount the drain lift and sink plug where the overflow valve is located. Install tiles with a maximum thickness of 8 mm including setting mortar.
- Cover the drain lift and sink plug with the fixture cover.
- The tub unit is now ready and can be filled with water after a drain connection test has been completed.