

Assembly Instruction


# wedi Fundo *Riolito* I Floor element



Information

Legend

- A Curb
- B wedi Fundo Riolito
- C Building Panel
- D Sealing collar
- E Screws
- F Drain body



Tool & Material

- Bucket
- Notch Trowel
- Drill with Thinset Mixer
- Utility Knife
- Straight Edge/T Square 5 ft or longer
- Speed Square
- Caulk Gun
- Handsaw
- Flat Head Screwdriver
- Cordless Drill or Hammer
- Solid Putty Knife
- Paper Towels
- Level
- Circular Saw
- Saw Horse
- Tape Measure
- Permanent Marker
- Extension Cord for Powertools
- PVC Pipe Cement Glue and Primer
- Inside PVC Pipe Cutter

Installation instructions wedi Fundo Riolito onto wooden floors

Before Installation

- Sub floor is level, sound and meets deflection criteria
- If Shower base is to be installed floor level, make sure you build out a stable depression and deep enough to receive base + thin set
- 2" PVC pipe is cut 1 1/8" below top of sub floor surface
- 2" drain assembly below floor is stabilized and will not sink under water load
- Make sure wedi drain and 2" pipe is safely connected using PVC cement and primer
- Only wedi products (wedi sealant, wedi fasteners, wedi building panel, wedi curb, wedi ramp) are used for wedi Fundo Riolito assembly
- Installer has been instructed by wedi staff or has been informed about proper wedi assembly steps through wedi installation brochure and video

After Installation

- All bottom perimeter joints, curb joints, vertical and horizontal panel joints are visibly covered with wedi sealants. Coverage should be continuously visible for at least 3/4" on each side of the joint.
- No mastic adhesives are to be used to install tile.




**1** Cut the 2" pipe 1 1/8" below the top of the subfloor surface of the floor construction. Make sure that the cut out fits to the Fundo panel drain. Cut out a 4 1/4" diameter hole around the 2" pipe to allow the wedi drain to be inserted into the subfloor. The drain and trap have to be sturdily fastened to the sub floor.



**2** Assemble the drain unit following the instruction drawing.



**3** Glue and seal the wedi drain body to the 2" pipe. Mount the sealing collar to the wedi Riolito underside counterpart.



**4** Skim coat the thinset ANSI 118.4 and comb through with a 1/4" x 1/4" notch trowel.



**5** Trowel the thinset on the rear side of the Fundo again using a 1/4" x 1/4" notch trowel.




**6** Press the Fundo firmly into the thinset bed, ensuring that the installation is level and void free. Apply some weight equally and for at least 30 minutes (thinset bags).




**7** Set up a continuous 1/2" bead of wedi sealant along the pans channel on the outer perimeter. Note that the wedi joint sealant starts setting up after 15 minutes. Set the beads separately for each panel installed.




**8** You are ready to install the wedi panels around the Fundo, fixed and sealed in the Fundo channels bead of sealant. Fasten the panels directly to the studs using one wedi fastener per foot. One extra fastener is set in between seams of panels to create a flush transition.



**9** Set up continuous 1/2" beads of sealant between and in all seams to adjacent panels. Excessive sealant is smoothed out using a putty knife. An additional 1/2" bead of caulk is set along the inside bottom joints connecting the wall panels and pan and spread flat over the joint. All fasteners are covered with sealant.



**10** wedi Niches are installed in a cut out in the wedi wall and attach with it's flange right into the center of 16 o.c. studs. wedi joint sealant is set along the connection of wall to niche.



**11** 2 Fasteners each side of the niche are set to create a flush transition to the wall panels. Another 1/2" bead of wedi sealant is spread over fasteners and seams.




**12** A continuous 1/2" bead of sealant is set into the channel and along the vertical curb notch part. A 1/2" bead of sealant is set against both wedi walls. A 1/2" bead of thin set mortar is set on the floor. The tightly cut to fit curb is pressed into the connection.


## Installation instructions wedi Fundo Riolito Drain Cover

### General Information

- A Drain Cover Fundo Riolito standard: Polished Stainless Steel Standard Version
- B Drain Cover Fundo Riolito exclusive: High Grade Stainless Steel Version
- C Drain Cover Fundo Riolito tileable: Can be tiled with epoxy glue/adhesive. Can be used for 1/4" and 1/2" tile/stone (reverse cover)



**1** Mount the screw heads to the threaded bolts inside the drain channel and bring them to the desired height so that the drain cover finish will sit slightly lower or flush with your tile or stone.



**2** Align the square screw heads so that the drain cover finish can be inserted. The screw heads will support the drain cover finish even under heavy duty conditions.



wedi corporation  
225 Peachtree St., N.E. · 1100 South Tower · Atlanta GA 30303 USA  
Tel.: +1-404-586-3472 · Fax: +1-404-223-0301  
info@wedincorp.com · www.wedincorp.com